

## Digital length measuring device SAUTER LB



Distance measurement directly in machines or sites with RS-232 interface

## Features

- **Digital sliding calliper with a superior precision** even at high operation speed
- **Easy mounting** to machine tools, conveyer, test stands etc.
- Zeroing, pre-added and pre-reduced length as well as switching the unit can be done manually
- **Data interface RS-232**, standard
- **Selectable measuring units:** mm, inch

## Technical data

- Dimensions housing W×D×H 77×43×34 mm
- Battery operation, batteries standard (3 V CR2032)

## Accessories

- **RS-232/PC connection cable**, SAUTER LB-A01
- **Mounting the length measuring device LB** onto a SAUTER test stand at the factory, SAUTER LB-A02

## STANDARD































## OPTION



Model	Measuring range [Max] mm	Readout [d] mm	Direction of measurement	Option Factory calibration certificate	
				KERN	
SAUTER					
LB 200-2.	200	0,01	vertical	961-150	
LB 300-2.	300	0,01	vertical	961-150	
LB 500-2.	500	0,01	vertical	961-150	

## Pictograms

 <b>Adjusting program (CAL):</b> For quick setting of the instrument's accuracy. External adjusting weight required.	 <b>Control outputs (optocoupler, digital I/O):</b> to connect relays, signal lamps, valves, etc.	 <b>Battery operation:</b> Ready for battery operation. The battery type is specified for each device.
 <b>Calibration block:</b> standard for adjusting or correcting the measuring device.	 <b>Analogue interface:</b> to connect a suitable peripheral device for analogue processing of the measurements	 <b>Rechargeable battery pack:</b> rechargeable set.
 <b>Peak hold function:</b> capturing a peak value within a measuring process.	 <b>Statistics:</b> using the saved values, the device calculates statistical data, such as average value, standard deviation etc.	 <b>Mains adapter:</b> 230V/50Hz in standard version for EU. On request GB, AUS or USA version available.
 <b>Scan mode:</b> continuous capture and display of measurements.	 <b>PC Software:</b> to transfer the measurement data from the device to a PC.	 <b>Power supply:</b> Integrated, 230V/50Hz in EU. More standards e.g. GB, AUS or USA on request.
 <b>Push and Pull:</b> the measuring device can capture tension and compression forces.	 <b>Printer:</b> a printer can be connected to the device to print out the measurement data.	 <b>Motorised drive:</b> The mechanical movement is carried out by a electric motor.
 <b>Length measurement:</b> captures the geometric dimensions of a test object or the movement during a test process.	 <b>GLP/ISO record keeping:</b> of measurement data with date, time and serial number. Only with SAUTER printers	 <b>Motorised drive:</b> The mechanical movement is carried out by a synchronous motor (stepper).
 <b>Focus function:</b> increases the measuring accuracy of a device within a defined measuring range.	 <b>Measuring units:</b> Weighing units can be switched to e.g. non-metric at the touch of a key. Please refer to website for more details.	 <b>Fast-Move:</b> the total length of travel can be covered by a single lever movement.
 <b>Internal memory:</b> to save measurements in the device memory.	 <b>Measuring with tolerance range (limit-setting function):</b> Upper and lower limiting can be programmed individually. The process is supported by an audible or visual signal, see the relevant model	 <b>DAKkS calibration possible:</b> The time required for DAKkS calibration is shown in days in the pictogram.
 <b>Data interface RS-232:</b> bidirectional, for connection of printer and PC.		 <b>Factory calibration:</b> The time required for factory calibration is specified in the pictogram.
 <b>Data interface USB:</b> To connect the measuring instrument to a printer, PC or other peripheral devices.		 <b>Package shipment:</b> The time required for internal shipping preparations is shown in days in the pictogram.
 <b>Data interface Infrared:</b> To transfer data from the measuring instrument to a printer, PC or other peripheral devices.	 <b>ZERO:</b> Resets the display to "0".	 <b>Pallet shipment:</b> The time required for internal shipping preparations is shown in days in the pictogram.

**Your KERN specialist dealer:**